Fastrax Tyre Truer Automatic
FAST2000



If cutter stops during forward or reverse motion, check that the fuse (1.5A) inside the cover has not blown.

FOR "ANGLE CUTS" LOOSEN SCREW UNDER BASE. SLIDE CUTTER RAIL FROM ZERO TO 2 DEGREES FOR AN ANGLE TIRE CUT. ANGLE DEGREE SCALE IS FOUND ON PLATE FACE.