



## C-00180-910 CHASSIS BRACE X-TREME

*It is necessary to drill 2 holes in the shocktower to install the kit.  
Only for the first generation of : Buggy (C-00181) and Monster Truck (C-00165 • C-00180-170)*

