



C-00180-910 CHASSIS BRACE X-TREME

*It is necessary to drill 2 holes in the aluminium shocktower to install the kit.
Only for the first generation of : Truggy (C-00175)*

