

## #80422 - Body Savers for the Traxxas Revo 2.0

**What's Included:** 2 - Front Body Savers, 2 - Rear Body Savers & 8 - M3 x 12mm buttonhead screws.

**Before Your Begin:** Remove the four front screws and four rear screws holding the body mounts (Traxxas #8615) to the body. You may discard the stock screws. They are no longer needed. If you leave the screws holding the body support (Traxxas #8613) in place, the front and rear body mounts will stay in place.

**Front Body Savers:** Review the illustration to the left. The Front Body Savers are directional. Make sure the round boss at the rear of the Body Savers drops into the hole location closest to the windscreen of your truck. For visual reference, the louvers should face towards the rear of the vehicle. Bolt in place using the included M3 x 12mm buttonhead screws.

**Rear Body Savers:** Review the illustration to the left. The Rear Body Savers are directional as well. Make sure the Rear Body Savers properly follow the contours of the rear of your truck. When properly placed, they'll fall right into their correct location. Bolt in place using the included M3 x 12mm buttonhead screws.

