

X250 WiFi Camera Installation

Kit Contains:-

Phone holder
Phone holder bracket
Thumb screws and nuts
FPV camera
Longer standoff feet



Installing the Phone Holder

1. Place the rear half of the phone holder bracket onto the back of the transmitter, the location lugs will line up with the holes on the transmitter



2. Place the front half of the phone holder bracket on the front of the transmitter in-line with the rear holder and screw in place with the two thumb screws and nuts provided.



3. Attach the Phone holder to the Phone holder bracket by connecting the two halves together.



4. Install your smart phone into the phone holder by pulling up on the tab. The holder is sprung loaded and will snap back into position to hold the phone.



5. Install the WiFi camera to the underside of the Quadcopter. The camera slides in from the back to the front and clips in place on the front lugs.



6. Plug the camera in to the WiFi port on the bottom of the Quadcopter. The WiFi port is the only connector with 3 connections.



7. You will also need to install four longer stand-offs to increase the standoff height to accommodate the camera.



8. Open the App on your smart phone to start using the WiFi Camera.