


RC4WD TDI ENGINE BAY FOR 2015 LAND ROVER DEFENDER D90



Instruction Manual Symbols Key



CA Glue



Trim with Hobby Knife



Drill Hole



Paint



Body Reamer



Attention



Cut with Scissors


Recommended Tools



(Foam safe CA, Shoe Goo, E6000, Styrene Glue, Epoxy)



Side Cutters



Hex Drivers (1.5mm, 2mm)



Hobby Knife

Tips for Assembly

- 1. Use good quality hex drivers to avoid stripping screw heads.
- 2. Use "Step" index for quantity and size of hardware to be used for assembly
- 3. Do not overtighten screws.
- Carefully remove all pieces from parts trees with a hobby knife or side cutters. Take care to trim the injection point from the parts.
- Test fit everything before gluing. Many areas will require extra attention to detail to ensure proper alignment.


Warranty

RC4WD non-electrical products are warranted to be free of defects in materials and workmanship when new. Our limited warranty does not cover damages due to normal wear and tear, user error of assembly or installation, user modifications, user's failure to perform routine maintenance, addition of aftermarket parts or option parts. This warranty lasts 30 days after arrival for original purchaser.


In the event of a defect under this warranty, RC4WD will, at our discretion, replace the product, provided our inspection indicates that an original defect exists. RC4WD reserves the right to replace any product which is no longer available with a product of comparable value and function. If RC4WD determines the repair is not covered under warranty guidelines, we will contact you to discuss your options. If you have any questions, please contact us via email at support@rc4wd.com.

RC4WD warranties its electronics for 30 days from date of arrival. This covers all electrical items except items that are already noted on the individual product page.

Parts List-1




Parts List-2




150-0327 M1.6 x 4mm SHSTS 150-0245 M2.5 x 4mm BHSTS 150-0171 M2.5 x 8mm BHSTS




Step 1.



Step 2.




Step 3.







Step 4.




Step 5.






Step 7.











Step 9.






Step 10.




Step 11.






Step 12.




Step 13.






Step 14.




Step 15.






Step 16.




Step 17.






Step 18.




Step 19. Apply stickers.






Step 20. Apply stickers




Step 21. Installation Complete!







Step 22. *The following are steps for installing Z-S0437 which is not included in this kit.





Step 23.















Step 27. *The following are steps for installing Z-S0437 which is not included in this kit.



Step 28.





www.rc4wd.com



GULIN

737 N. Gateway St. Visalia, CA 93291