





Rear Assembly


ESC

Steering Assembly





Motor Assembly






FRONT & REAR SHOCK ASSEMBLY




B O M

TYPE	ICON	SPEC	QTY
Round Head Self Tapping Hex Screw		2x10	4
Button Head Hex Screw		M3x12	2
Cap Head Hex Screw		M3x8	4
		M3x10	2
		M3x12	10
		M3x14	3
		M3x16	4
		M3x18	2
		M3x20	2
Set Screw		M3x3	2
		M4x4	1
		M4x10	2
Ring Self Tapping Screw		3x4	2
Washer		ø6x3.1x0.2	2
Nylon Lock Nut		M3	2
E clip		ø2.5	5
O'Ring		ø6.05x4.25x1.05	4
		ø6.3x4.25	4
		ø15.8x12.8x1.5	2
		ø15x10x4	2
Ball Bearing		ø10x5x4	6

Front Assembly




Gearbox Assembly




Diff Box

Diff. Box



Rear Assmebly



B O M

TYPE	ICON	SPEC	QTY
Round Head Self Tapping Hex Screw		2x10	4
Button Head Hex Screw		M3x8	2
		M3x10	7
		M3x12	6
Cap Head Hex Screw		M3x10	2
		M3x12	1
		M3x14	4
		M3x16	4
		M3x18	2
		M3x20	2
Set Screw		M4x4	1
		M4x10	2
Ring Self Tapping Screw		3x4	2
Washer		ø6x3.1x0.2	2
Nylon Lock Nut		M3	3
E clip		ø2.5	5
O'Ring		ø6.05x4.25x1.05	4
		ø6.3x4.25	4
		ø15.8x12.8x1.5	2
		ø15x10x4	2
Ball Bearing		ø10x5x4	6

