
# **BATTERY PACK & CHARGER MANUAL**



#### MBC-24JST USB Charger

This charger is designed to charge the included 7.2V NiMH packs only. DO NOT charge any other type of battery. It is NOT intended for LiPo or Li-ion packs; or packs of a lower or higher voltage rating. When connected to a standard USB power source (500 mA or above is recommended), a red LED will light up indicating that the power is ON. During charging the maximum charging current is approx 100mA, and when the pack is fully charged, the charging current will drop. A typical time to fully charge a completed drained battery is 2 hours. After charging, disconnect the USB charger, and the pack. It is normal for the pack itself to feel slightly warm after charging.

NOTE: A partly discharged pack will take shorter time to be fully charged. BUT, due to the physiology of the NiMH packs, and their tenancy for memory effect, it is always best to fully discharge and cycle NiMH packs. It may take a few cycles for your pack to reach its full potential.

REMEMBER: younger RC fans must always charge the pack under adult supervision, and never leave the charging pack unattended. The red LED will NOT turn off, it only indicates that USB power is present. It is advised that you set a timer to independently notify you when the 2 hour charge cycle is complete. Failure to adhere to the correct charging procedure can lead to permanent damage to the pack, and in extreme cases, fire or personal injury. Charge smart, charge safe, follow guidelines.

# **SPARE PARTS**

15389	GT24B Hardware Set	15451	GT24B Spur Gear 59T
15390	GT24B Servo Saver and Mount	15452	GT24B Front Bumper Set
15392	GT24B Front Gear Box Housing	15653	Micro Car Body Clip
15393	GT24B Rear Gear Box Housing	15752	GT24i20 Front Wheel and Tire Set
15394	GT24B Differential Gear Set		Assembled (pair 2 pcs)
15395	GT24B Center Drive Shaft Set	15753	GT24i20 Dog Bone (pair 2 pcs)
15396	GT24B Slipper set	15754	GT24i20 Shocks Assembled (pair 2 pcs)
15401	GT24B Motor Mount Set	15755	GT24i20 Steering Linkage
15404	GT24B Outdrive set	15756	GT24i20 Front Suspension Arm Set
15405	GT24B Front Shock Tower	15757	GT24i20 Rear Suspension Arm Set
15406	GT24B Rear Shock Tower	16125	GT24 ESC/RX Module N Version
15410	GT24B Front Hub Set	16126	GT24 Subaru Clear Car Body Set
15411	GT24B Rear Hub Set	16130	GT24 Subaru Decal Sheet Set
15413	GT24B Chassis and Cover Set	16131	GT24 Subaru Wheel Set (4pcs)
15414	GT24B Body Post and Battery Cover	16132	GT24 Subaru Tire Set (4pcs)
15415	GT24B Bearing Set	16124	GT24 Subaru Painted Body Set
15416	GT24B Plastic Screw Nut For Wheel		



15434 GT24B Replacement Servo

8000KV Mini 130 Brushless Sensorless









USB

Charger

Transmitter













# PREZA WRG 2000





POSSIBLY THE COOLEST MICRO RALLY ON THE PLANET








TOOLS RECOMMENDED

(NOT INCLUDED)

Long Nose Pliers

# WHAT'S IN THE BOX





7.2V NIMH **Battery Pack** 





Nippers

# SAFETY PRECAUTIONS



THIS MODEL IS ONLY SUITABLE FOR PEOPLE 14 YEARS OLD AND UP. THIS BADIO CONTROL MODEL IS NOT A TOY.

Reginner should seek advice from experienced, person in order to assemble the model or parts correctly and to make best performance Assemble this model or parts only in place out of children's reach, and take safe precautions before operating this model. User is fully responsible for the model assembly and safe operations

#### Introduction

This is a sophisticated hobby product and not a toy. It must be operated with caution and common sense. User also requires some basic mechanical abilities. Fall to operate this product in a safe and responsible manner could result in injury or do damage to the product or other properties. This product is not intended for use by children without direct adult supervision. The product manual contains instructions for safe operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual prior to assembly, setup or use, in order to operate correctly and avoid damage or injury.

#### Safety, Precautions, and Warnings

As the user of this product, you are solely responsible for operating it in a manner that does not endanger yourself and others or result in damage to the product or the property of others.

This model is controlled by a radio signal that is subject to interference from many sources outside your control. This interference can cause momentary loss of control so it is necessary to always keep a safe distance in all directions around your model, as this will help to avoid collisions or injury.

- Always operate your model in an open area away from cars, traffic, or people.
- Avoid operating your model in an operate a away from cars, traine, to people.
   Avoid operating your model on the street where injury or damage can occur.
   Never operate the model out into the street or populated areas for any reason.
- Never operate your model with low transmitter batteries.
   Carefully follow the directions and warnings for this product and any optional support.

- Carefully follow the directions and warnings for this product and any optional suppor equipments (chargers, rechargeable battery packs, etc.) that you use.
   Keep all chemicals, small parts and anything electrical out of the reach of children.
   Moisture causes damage to electronics, Avoid water exposure to all equipments not specifically designed and protected for this purpose.

#### CE Compliance Information For The European Union

Carisma hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the RED Directive 2014/53/EU, FN 301 489-1 V211 FN 301 489-17 V311 FTSI FN 300 328 V211

The associated regulatory agencies of the following countries recognize the noted certifications for this nroduct as authorized for sale and use

						ES						
FI	EE	LV	LT	PL	AT	CY	SI	GR	МТ	IT	IE	LU

Products: CTX-2000, MRS-24BL Equipment Class: 2

FCC Information FCC ID YDTCTX-2000 Item Name : CTX-2000 2.4GHz Transmitter

The objects of declaration described above are in conformity with the requirements of the specifications listed below. Manufactured By : Mun Ah Plastic Electronic Toys Company, Ltd Statement - This device complies with Part 15 of the FCC Rules.

Statement - This device compiles with Part 15 or the PCC Rules.
Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Warning:

This equipment compiles with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment compiles with FCC radiation exposure limits set forth for an uncontrolled environment.

### Instructions for Disposal of WEEE by Users in the European Union

This product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collection point for the recycling of waste lectrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or where you purchased the product.

#### NCC Warning Statement

Article 12
Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristic and functions of the original design of the certified lower power frequency electric machinery.

Article 14
The application of lower power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists.

#### FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide residential protection against harmful interference in a residential installation. This equipment generates, uses. and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures: Recrient or relocate the receiving antenna. Increase the separation between the equipment and the receiver. Connect the equipment of an acticult different from that to which the receiver is connected.

The equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. Modifications not authorized by the manufacturer may void the user's authority to operate this device. This device compiles with part 15 of the FCC Rules. Operation is subject to the following two conditions (1), This device may not cause harmful interference, and (2) this device must accept any interference received, including

Interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

# STUDY THE INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY

There are many small screws, nuts and similar parts. Please refer to the column on the left to know the exact size. To prevent trouble and finish the model with good performance, it is necessary to assemble each step exactly as shown

# ABOUT THE RADIO SYSTEM

# CTX-2000 2.4GHz FHSS Technology System

The following is an overview of the various functions and adjustments found on CTX-2000 radio system. It is important to read and understand about all of these functions and adjustments before driving.

#### FUNCTIONS

TRANSMITTER CTX-2000 Steering Wheel: Control direction (Left/Right) of the RC model.

Throttle Trigger: Control speed and direction (Forward/Brake/Backward) of the driving model.

ON / OFF Switch : Power ON / OFF the transmitter.

SW1 Button: Is used to synchronize the connection between the transmitter and the receiver. It also serves as additional function on different model.

LED Indicator: For indicating battery low, pairing in progess and normal operation.

ATV : Adjust the maximum steering angle on both sides when model turns Left / Right

ST. Trim Dial: Adjust the neutral position of steering servo when model wheels are straight ahead.

TH. Trim Dial: To adjust the throttle position

Steering Reverse: Reverse the response direction when operating Steering Wheel Throttle Reverse: Reverse the response direction when operating Throttle Trigger. Throttle Limit Switch: Set the max Forward Speed of the model

\* In general, user will experience under steer when making a wide turn at high speed or over steer when making sharp turn at high speed (easy to spin out). User should practice the Throttle and steering approach for different cornering at different speed or road surface.

#### **Battery Installation**

1. Supplied with 4 x 1.5V AA Batteries, radio can be operated a few hours. Installation: Remove the battery compartment cover as shown below.

2.Install the batteries observing the polarity marked on battery compartment.

3.Then reinstall the battery compartment cover as the Picture shown below

Steering Reverse

ON/OFF

ΔTV

SW1 Button

Switch

TH. Trim Dial ST. Trim Dial

LED Indicator

# Warning:

Never disassemble batteries or put the batteries in fire, chemical agents, otherwise they may cause personal injuries or property damages.

Throttle Reverse Throttle Limit Switch

Steering

Wheel

Throttle

Trigger


#### **Battery Disposal:**

Observe corresponding regulations about wasted battery treatment regulations. 1. After running out of power, dispose of wasted batteries in designated areas far away from water supply, household areas and planted areas

2. Submit the wasted batteries to specific recycling stations

### **Battery LED Indicator**

The LED solid on indicating that the batteries have sufficient power. When batteries voltage drops below 4 volts, LED will Flash. indicating batteries power is low and should be replaced.




### ATV


12

ATV enables to adjust the maximum steering angle of servo on both sides (Left and Right) when model makes steering. The ATV affects the sensitivity of servo. Reducing dual rate value can lower the sensitivity of servo and reduce the same maximum steering angle on both sides. Remember to

adjust the ATV within the adjustment range.



#### Pre-Run Check



1. Steering: Adjust the steering trim to keep the front wheels in straight line when steering wheel remains in NEUTRAL position.

2. Throttle: Adjust the throttle trim to make the motor stop while throttle trigger at NEUTRAL position.

\* Always turn on the transmitter first. If the LED is not solid on, you need to check whether he batteries are good or incorrectly installed.

#### Reversing

Steering Reverse: Reverse the response direction when operating steering wheel. Turning left steering wheel, the model turns right

while turning right the model turns left. Throttle Reverse: Reverse the response direction when operating throttle trigger. Pushing forward throttle trigger the model moves backward while pulling back, the model moves forward. If necessary you can just use a small screwdriver to adjust the responding switches



#### Throttle Limit Switch

The slide switch to select the max forward speed:

- 1: Slowest
- 2: Intermediate
- 3. Fastest



2


# RECEIVER CONNECTION AND INSTALLATION


#### Carisma MRS-24BL RX/ESC Unit Synchronization

#### To Sync the Radio to the Car

STEP 1: Locate the SYNC button on the main chassis by removing the body (the Round button)









STEP 3: Press and HOLD the Chassis SYNC Round Button while Power ON






STEP 4: The LED will flash, release the SYNC button





STEP 5: PRESS and HOLD the SW1 button on the transmitter and Power ON



# RECEIVER CONNECTION AND INSTALLATION

STEP 6: Car LED should be ON SOLIDLY and its now READY to play. If fail to connect. Repeat from step 1 again.







# MRS-24BL RX/ESC UNIT SETUP

#### **ESC SETUP**

Just use the TH. Trim to locate the Neutral Position. Nothing else to set. The ESC is a Forward and Brake/Reverse function.





## **WARNING:**

Maximum is 2S LiPo (7.4V) DO NOT EXCEED this voltage, otherwise will damage and void warranty.

# CARISMA MRS-24BL RX/ESC UNIT FEATURES

# 1. LED indicator The LED serve two function:

a. Indicate present of TX

b. Indicate the Battery Type selected

Solid ON = NiMH Flashing = LiPo

#### 2. Setting Battery Type

a. TX power on and at stop position

b. Power RX, wait for few second, and then press and hold the RX button until LED changed, new battery type is updated.

#### 3. Power Off reminder

After loss of TX signal over 5 sec, will use LED and servo to warn the user to POWER OFF the car, to avoid over discharge and damaging the battery.

- . LED quickly flashed 2 times per 2 sec
- Servo will be moved once shortly per 10 sec.

15

