INSTRUCTION MANUAL
AX90050-1001

YETI™

SCORE® TROPHY TRUCK®

READY-TO-RUN • BRUSHLESS

1/10th SCALE ELECTRIC 4WD

axial®

www.axialracing.com

CAUTIONS

To prevent serious personal injury and/or property damage, operate all remotely controlled models in a responsible manner as outlined herein.

CHOOSE THE RIGHT PLACE TO OPERATE YOUR R/C MODEL.

- Do not run on public streets or highways. This could cause serious accidents, personal injuries, and/or property damage.
- Never run R/C models near people or animals.
- To avoid injury, do not run in confined spaces.
- Do not run where loud noises can disturb others, such as hospitals and residential areas.
- Never run indoors. There is a high risk of fire and/or damage.

INSPECT YOUR MODEL BEFORE OPERATION.

- Make sure that all screws and nuts are properly tightened. It is also a good idea to use removable thread lock wherever metal screws go into metal, especially for engine mounts.
- Always use fresh batteries for your transmitter and for your receiver to avoid losing control of the model.
- Always test the brakes and throttle before starting your engine to avoid losing control of the model.

AFTER OPERATION OF YOUR R/C MODEL

- Turn off receiver first, then turn off transmitter, this will prevent runaways.
- Be careful when handling batteries, they will be hot after running.
- Replace any batteries that have been dented or have frayed wires, short circuits can cause fire.
- Be sure to keep your R/C model clean and free of excess dirt and grease, this will increase the life.
- Disconnect the battery from the ESC whenever the vehicle is not in use.

VORSICHT!

Um Verletzungen an Personen und/oder Sachschäden zu vermeiden, sollten alle ferngesteuerten Modelle sorgfältig und verantwortungsbewusst bedient werden,wie nachfolgend beschrieben.

Wählen Sie den richtigen Platz zum Fahren

- Fahren Sie niemals auf öffentlichen Straßen. Dies könnte Verkehrsunfälle, Personen schäden oder Sachschäden verursachen.
- Fahren Sie niemals in der Nähe von anderen Personen oder Tieren.
- Fahren Sie niemals auf belebten Straßen.
- Fahren Sie nie in der Nähe von Wohnhäusern oder Krankenhäusern. Der Lärm könnte andere Personen stören.
- Fahren Sie niemals in Innenräumen. Dort könnte etwas beschädigt werden.

Überprüfen Sie Ihr Modell, bevor Sie es in Betrieb nehmen.

- Gehen Sie sicher, dass alle Schrauben und Muttern festgezogen sind. Verwenden Sie überall dort Schrauben-Sicherungslack, wo Metallschrauben in ein Metallgewinde greifen, besonders bei den Motorhaltern.
- Um Störungen zu vermeiden, benutzen Sie immer voll geladene Akkus in Ihrem Sender und Empfänger.
- Bevor Sie den Motor starten, sollten Sie immer die Funktion der Bremse und des Gashebels testen.

Nach Betrieb des RC Modells:

- Zuerst den Empfänger abdrehen, dann den Sender abdrehen um unkontrolliertes Durchgehen zu vermeiden.
- Seien Sie vorsichtig mit gebrauchten Akkus, sie können nach dem Gebrauch heiß sein.
- Ersetzten Sie Akkus/Batterien die beschädigt sind oder schadhafte Kabel aufweisen, sie können Kurzschlüsse oder Feuer verursachen.
- Halten Sie Ihr Fahrzeug sauber und entfernen Sie Schmutz und Schmierfett, damit erhöhen Sie die Lebensdauer Ihres Modells.

PRECAUTIONS

Afin d'éviter toutes blessures corporelles et/ou dommages environnants, veuillez procéder en toute responsabilité comme indiqué ci-dessous

Choisir le lieu adéquat pour faire rouler votre modèle.

- Ne jamais rouler dans les rues ou sur les routes ouvertes au publique. Ceci peut provoquer de graves accidents.
- Ne jamais rouler près de personnes ou d'animaux.
- Pour éviter les blessures, ne pas rouler dans des espaces confinés.
- Ne jamais rouler où le bruit peut déranger, comme aux abords des hôpitaux ou des quartiersrésidentiels.
- Ne jamais rouler à l'intérieur: les gaz d'échappement sont nocifs.

Controler votre modèle avant chaque utilisation.

- Vérifier que les vis et les écrour sont bien serrés. Il est trés fortement conseillé d'utiliser du frein filet pour bloquer les vis qui sont en contact avec du métal et tout particulierer ment les vis du moteur.
- Toujours utiliser des batteries bien chargées pour l'émission et la réception.
- Toujours vérifier les freins et la commande des gaz avant de démarrer.

Après l'Opération De Votre Modèle de R/C

- Le virage du récepteur premier, alors virage de l'émetteur, ceci empêchera des fugitifs.
- Faire attention en contrôlant des piles, ils auront chaud après avoir couru.
- Remplacer n'importe quelles piles qui ont été cabossées ou a éraillé des fils, les court-circuits peuvent causer le feu.
- Etre sûr de garder votre modèle de R/C nettoie et libère de terre et la graisse supplémen taires, ceci augmentera la vie.

Included items / Im Baukasten enthalten / Outils inclus dans le kit

2.4GHz
Transmitter
Sender
Emetteur

Cross wrench
Steckschlüssel
Clé à tube

Equipment needed / Benötigtes Zubehör / Equipement nécessaire

x4

4 AA Alkaline Dry Batteries.
4 St. AA Trockenbatterien.
4 piles type R6 pour votre radio commande.

Battery Li-Po or NiMH
Akku-Pack
Pack de batterie

Charger
Ladegerät
Chargeur

Tools Recommended / Benötigte Werkzeuge / Outillage

Hex wrench
Inbusschlüssel
Clé Allen

Side cutter
Seitenschneider
Pinces coupantes

Curved scissors
Schere
Ciseaux

Long nose pliers
Flachzange
Pinces à becs longs

Modeling knife
Modelliermesser
Couteau de modéliste

Getting Started / Angefangen Zu Werden / Commencer

Charge your battery / Laden des Fahrakkus / Chargement de la batterie

Follow the manufacturer's directions for the charger you purchased to properly charge your batteries.

Folgen Sie den Herstellernrichtungen für den Auflader Ihres gekauft ordentlich, Ihre Batterien zu laden.

Suivre les directions de fabricants pour le chargeur votre a acheté convenablement pour charger vos piles.

!

Do not use a Nickel Cadmium or Nickel Metal Hydride battery charger to charge LiPo batteries. Damage to the batteries and charger will likely occur resulting in a fire.

Verwenden Sie keine Nickel-Cadmium-oder Nickel-Metall-Hydrid-Akku Ladegerät LiPo-Akkus aufladen. Schäden an den Batterien und Ladegerät wird wahrscheinlich auftreten, was zu einem Brand.

Ne pas utiliser un chargeur de batterie au nickel-cadmium ou nickel-métal-hydrure pour recharger les batteries LiPo. Les dommages aux batteries et le chargeur se produira probablement de provoquer un incendie.

Battery Tray Adjustment

1.Remove clip to open battery access door

2.Slide battery into try to check clamp height

3.Remove x4 M3x8mm AXA114 screws

4.Adjust battery clamp to fit snug against battery.

5. Reinstall x4 M3x8mm screws

6. Close battery access door and insert clip

1 Remove the body and install the battery.

2 Reattach body to vehicle.

3 Turn on the transmitter.

4 Turn on the electronic speed controlle

* If your ESC does not have a power switch. The power is controlled by connecting the battery.

Top View Parts

Getting-Started Checklist

The following checklist is a guide for getting you vehicle running for the first time.

☐ Read 'Cautions' in Manual. (Page 2)

☐ Familiarize yourself with vehicle and its components.

☐ Even though the vehicle is new check driveshaft setscrews and other screws to make sure they are tight from the factory.

☐ Charge battery pack. (Page 4)

☐ Install 4X AA batteries into Transmitter. (Page 7)

☐ Install battery pack in vehicle. (Page 4)

☐ Turn on transmitter FIRST then ESC. (Page 4)

☐ Check to make sure steering and throttle operation work correctly. (Page 7)

☐ Range check radio system. (Next Page)

☐ Drive vehicle, challenge yourself and have fun!

☐ Maintain vehicle. (Next Page)

Range-Checking Your Radio System

The radio system should be checked before operating the vehicle to ensure it's operating properly and has adequate range.

1. Turn on the transmitter first and then the vehicle.
2. Have a friend hold the vehicle while keeping hands and loose clothing away from moving parts.
3. Walk away until you are at the farthest distance you plan to operate the vehicle.
4. Steer the vehicle back and forth and throttle both forward and reverse making sure there is no erratic behavior.
5. If any erratic behavior is exhibited do not operate the vehicle, call customer service for further assistance.

RANGE-CHECKING FOR DISTANCE

Maintaining Your Vehicle

Just like a full size car or truck your RC vehicle must undergo periodic maintenance in order to ensure peak running performance. Preventative maintenance will also help avoid needless breakages which could result in costly repairs. Below are some suggestions to properly maintain your vehicle.

AE-3 Vanguard Forward/Reverse Brushless ESC Instruction

Recommended motor: AX31047

Brushless ESC and Motor Setup:

- Mount the ESC in an area that is well ventilated and isolated from vibration and shock.
- Connect the ESC wires to the motor. Generally A to A, B to B, and C to C.
- Plug the receiver wire into the throttle channel on the receiver.
- Before plugging the battery into the ESC, make sure your transmitter is on and the throttle trim is set to zero.
- Plug in the battery to the ESC with the ESC switch in the OFF position.
- Apply full throttle on the transmitter.
- Turn on the ESC switch while applying full throttle.
- The ESC will emit a series of beeps with the red LED.
- Continue applying full throttle until the ESC blinks green and emits a series of beeps.
- Once the ESC blinks red, apply full brake (reverse) on the transmitter.
- The ESC will emit a series of beeps while blinking red to finalize the brake/reverse endpoint.
- Return the throttle to the neutral position and the ESC will emit a series of beeps to finalize the neutral point.
- The ESC will emit a final series of beeps confirming the ESC is ready to operate.
- Apply throttle to make sure the motor is going the direction you wanted.
- To reverse the direction of the motor, switch two of the wires going to the motor.

Specifications:

Input voltage:	3S Lipo/8 NiCELL
Size:	1.95inx1.51in
Weight:	62.3grams
On-Resistance FET:	.00055 Ohms (per phase)
BEC Voltage/A:	5.0V 2.0A Peak
PWM Frequency:	12 KHZ

Notes:

- If the ESC setup does not initialize when holding the full throttle, try switching the throttle reversing switch on the transmitter.
- LiPo Cut-Off is set to "ON" from the factory
- Use the CastleLink (Optional, not included) to access the advanced settings available in the ESC.
- Visit http://www.castlecreations.com/ for more informtaion on the CastleLink USB Programming Kit.

CAUTION

CONNECT THE BATTERY PACK JUST BEFORE DRIVING AND DISCONNECT IT IMMEDIATELY AFTER.
ALWAYS MAKE SURE YOU ARE CONNECTING THE ESC TO A PROPER POWER SOURCE THAT HAS THE CORRECT VOLTAGE & POLARITY. INCORRECT VOLTAGES OR REVERSED POLARITY WILL DAMAGE THE ESC.
ONCE THE BATTERY PACK IS CONNECTED, HANDLE THE MODEL WITH EXTREME CARE, MAKE SURE YOU ARE CLEAR OF ALL ROTATING PARTS.

NOTES

Gear Ratio / Getriebeübersetzung

Use this equation to calculate the final drive ratio.
Final Drive Gear Ratio = (Spur/Pinion)x5.67

Mit dieser Gleichung können Sie die Gesamtübersetzung berechnen.
Gesamtubersetzung = (Spur/Pinion)x5.67

Slower - More Torque
Langsamer - Mehr Kraft

Faster - Less Torque
Schneller - Weniger Kraft

32 Pitch 38T/13T (Stock Gearing AX30392 or HD AX30395)				
	Spur Gear			
Pinion	56	60	64	68
11	28.85	30.91	32.97	35.03
12	26.44	28.33	30.22	32.11
13	24.41	26.15	27.90	29.64
14	22.67	24.88	25.90	27.52
15	21.15	22.67	24.18	25.69
16	19.83	21.25	22.67	24.08
17	18.67	20.00	21.33	22.67

32 Pitch 36T/14T (Overdrive HD Gearing AX30401)				
	Spur Gear			
Pinion	56	60	64	68
11	25.38	27.19	29.00	30.81
12	23.26	24.92	26.58	28.25
13	21.47	23.01	24.54	26.07
14	19.94	21.36	21.94	22.60
15	19.61	19.94	21.27	22.60
16	17.45	18.69	19.94	21.18
17	16.42	17.59	18.77	19.94

32 Pitch 43T/13T (Underdrive HD Gearing AX30402)				
	Spur Gear			
Pinion	56	60	64	68
11	32.64	34.97	37.31	39.64
12	29.92	32.06	34.20	36.33
13	27.62	29.59	31.57	33.54
14	25.65	27.48	29.31	31.14
15	23.94	25.65	27.36	29.07
16	22.44	24.04	25.65	27.25
17	21.12	22.63	24.14	25.65

Warranty Info

AXIAL LIMITED WARRANTY

Your Axial product is warranted to be free of defects in materials and workmanship when new in the factory sealed box. This warranty does not cover damages due to normal wear and tear, users' failure to perform routine maintenance, error of assembly or installation, modifications or addition of aftermarket parts or option parts. This warranty lasts as long as the original purchaser owns the product and is not transferable (verified by dated itemized sales receipt accompanied with product). In the event of a defect under this warranty, Axial will, at our discretion, repair or replace the product, provided our inspection indicates that an original defect exists. Axial provides a 10-day warranty from the date of purchase on electronics (i.e. servo, esc, radio). Axial reserves the right to replace any product which is no longer available with a product of comparable value and function. If Axial determines the repair is not covered under warranty guidelines, there could be a charge applied for the repair and return shipping charges. Note: Purchasing products from unauthorized distributors may void warranty and prevent support and service.

INTERNATIONAL CUSTOMER WARRANTY

Please return product to the dealer where the purchase was made. If your Axial product purchase was made through an on-line retailer, any warranty issues must be taken care of by that retailer. Axial assumes no responsibility for Axial products sold internationally by on-line retailers.

REPAIR

For warranty repair, please contact Axial Customer Service at (877) 64-AXIAL (877-642-9425).

HOURS AVAILABLE:

8:00 am - 5:00 pm Monday through Friday, Central Time.

Rear Suspension Tuning Upper Link Adjustments

•AX31104 Mounts can be installed on either side of the AX31103 Chassis Tub

•Swapping the AX31104 mounts will provide a suspension more suited to low speed technical terrain. This also requires flipping the upper shock bushings. The RTR stock setup is more suited for high speed stability.

•Upper Shock bushings rotated to relocate shocks and line up with AX31109 Lower Links.

•Moving the upper links at the chassis will change the anti-squat characteristics of the Yeti under power.

•RTR Stock: Upper hole, more Anti-Squat for more rear traction under power.

•Optional lower holes, less Anti-Squat for less rear traction under power.

Gear Mesh Adjustment

•Remove X2 M2.6x8mm AXA0413 Flatheads from AX31107 Spur Cover to gain access to spur and pinion

•Loosen X2 M4x12mm AX31121 Capheads from AX31106 Motor Mount Clamp

•Rotate the motor and motor mount assembly to fine tune gear mesh

Trouble Shooting / Fehlerbehebung / Dépannage

Problem Problem Problème	Cause Grund Cause	Remedy Lösung Remède
Does not move Das Auto fährt nicht Le véhicule ne boughe pas	Batteries are not installed properly in the transmitter. Die Batterien sitzen nicht korrekt im Sender. Les piles ne sont pas placées correctement dans l'émetteur. Weak or no battery in model. Leerer oder kein Akku im Auto. Batterie faible ou non installée Damaged motor. Kaputter Motor. Moteur endommagé Frayed or broken wiring. Beschädigte Verkabelung. Câble dénudé ou coupe ESC is shut down by heat protection circuit. Notabschaltung des Reglers wegen Überhitzung. Le système ESC est fermé par le circuit de protection thermique.	Make sure batteries are properly installed. Legen Sie die Batterien korrekt ein. Positionnez correctement les piles dans l'émetteur. Install charged battery. Einbauen eines geladenen Akkus. Mettez en place une batterie chargée Replace with new motor. Austausch durch einen neuen Motor. Remplacez par un nouveau moteur Splice and insulate wiring completely. Erneuern und isolieren Sie die kaputte Stelle. Faites une épissure et isolez complètement le câble. Stop driving immediately, do not drive the car until the Speed Controller cools down. Fahren Sie nicht weiter. Warten Sie bis der Fahrten regler abgekühlt ist. Arrêtez immédiatement de conduire, ne pilotez pas la voiture tant que le contrôleur de vitesse n'a pas refroidi.
No Control. Keine Kontrolle über das Auto Pas de contrôle	Improper antenna on transmitter or model. Zu kurze Antenne am Sender oder Auto. Antenne inadéquate sur l'émetteur ou le véhicule Weak or no batteries in transmitter or model. Leere oder keine Batterien im Sender oder Auto. Batterie faible ou absente dans l'émetteur ou le véhicule. Neutral position or trim is incorrect. Neutralposistion oder Trimmung sind verstellt. La position neutre est incorrecte ou le trim n'est pas réglé. Are the receiver and battery connections properly connected? Sind der Empfänger und die Batterieverbindungen ordentlich verbunden? Son conectadas apropiadamente las conexiones del receptor y la batería?	Install charged or fresh batteries. Einbauen voller Batterien. Mettez des batteries rechargées ou neuves. Fully extend antenna. Ziehen Sie die Antenne vollständig aus. Dépliez complètement l'antenne. Adjust the steering trim. Stellen Sie die Lenkungstrimmung neu ein. Réglez le trim de direction. Check receiver and battery connections. Prüfen Sie Empfänger und Batterieverbindungen. Compruebe conexiones de bateria y receptor.
Steering and Throttle Function Reversed. Lenkung und Gas funktion-ieren genau verkehrt herum. Direction et accélération inverses.	Servo reverse switch is in wrong position. Servorichtungs-Schalter ist in der falschen Position. L'interrupteur de marche arrière du servo est dans la mauvaise position Please check that the wires from ESC to motor are connected properly. Bitte überprüfen Sie, ob die Kabel vom Regler zum Motor richtig sitzen. Veuillez vérifier que les fils allant de l'ESC au moteur sont correctement raccordés.	Set to correct position. Satz, Position zu korrigieren Vérifiez la position correcte Check to make sure motor and ESC are properly connected. Kontrolle sich zu vergewissern, dass Motor und ESC ordentlich verbunden sind. Le contrôle pour assurer que le moteur et ESC est conven-ablement connecté.

Parts Reference / Übersicht aller Teile / Référence des pièces

AX80006 x1
Servo Set

AX80018 x2
Hardware Parts Tree

AX80033 x2
10m Shock Parts Tree 1

AX80091 x1
EXO Bulkhead

AX31300 x2
10mm Shock Parts Tree 2 (Blue)

AX80071 x1
AR60 OCP Straight Axle Adapter

AX80070 x1
AR60 OCP Differential Cover

AX31301 x2
10mm Shock Caps Parts Tree (Blue)

AX80069 x1
AR60 OCP Axle Housing

AX80072 x1
AR60 OCP 4-Link Mount

AX31306
TT-380 SCORE® Trophy Truck® Grille and Cage **x1**

AX80119
EXO RTR Links Parts Tree **x1**

AX31266
IFD Hex Hub Adapter

AX31266
IFD Hex Hub Adapter

AX80106
EXO Steering Knuckle Carrier Set **x1**

AX31110
Yeti™ Steering Knuckle Set **x1**

AX31111
Yeti™ Shock Tower and Body Post Set **x1**

AX31104
Yeti™ Chassis Components **x1**

AX31113
Yeti™ Rear Sway Bar Mount Set **x1**

AX80111
EXO Lower Front Control Arms Set **x1**

AX31122
Yeti™ Front Bumper Set **x1**

AX31067
Slipper Plate **x1**

AX31105
Yeti™ Chassis Electronic Components **x1**

AX31107
2-Speed Hi/Lo Transmission Spur Gear Cover **x1**

AX31309
2.2 3.0 Method 105 Wheels - 41mm **x4**

AX31059
Slipper Plate **x2**

AX31106
2-Speed Hi/Lo Transmission Motor Mount **x1**

AX80002
Diff Case -Small **x2**

AX31125
Yeti™ Fuel Cell **x1**

AX31114
WB8-HD Driveshaft **x1**

AX31108
2-Speed Hi/Lo Transmission Case **x1**

AX31065
Spur Gear 32P 64T **x1**

AX31109
Yeti™ Rear 4 Link Set **x1**

AX31068
Slipper Pad
32.8x15.2x1mm (2pcs) **x2**

AX31305
TT-380 Rear Lower Cage and Tire Retainer **x1**

AX31308
TT-380 Front Bumper and Toe Block **x1**

AX31049
Helmet Set (Black) **x2**

AX31102
Yeti™ Rear Cage Components **x1**

AX31304
TT-380 Rear Cage Sides and Rear Upper Cage **x1**

AX31103
Yeti™ Molded Chassis Tub **x1**

AX31307
TT-380 Body Post Set **x1**

AX31083 Radio Box Seals x1
AX31083 Radio Box Seals x1
AX30382 EXO Steering King Pin x4
AX31131 T-Case Gear Set x1
AX31134 2-Speed Hi/Lo Transmission Output Shaft x1
AXA1635 M3x35mm Turnbuckle x1
AX30408 Input Shaft 5x29mm x2
AX31148 WB8-HD Driveshaft Coupler Set x2
AX31148 WB8-HD Driveshaft Coupler Set x1
AX30383 EXO Heavy Duty Differential Input Shaft x1
AX30381 EXO Heavy Duty Differential Output Shaft x2
AX30366 Axle 5x35mm x2
AX30147 Shock Shaft 3x53.5mm x2
AX31054 Shock Shaft 3x71mm x2
AX31129 2-Speed Hi/Lo Transmission Bottom Shaft (5x75mm) x1
AX31127 2-Speed Hi/Lo Transmission Top Shaft (5x91mm) x1
AX30418 Dogbone 7x96mm x2
AX31139 Center Universal Shaft 103mm x1
AX30776 Rear Axle Shaft 6x104.2mm x1
AX30776 Rear Axle Shaft 6x160.2mm x1
AX31130 High Speed Transmission Gear Set x1
AX31130 High Speed Transmission Gear Set x1
AX31131 T-Case Gear Set x1
AX30390 Differential Gear Set x2
AX30390 Differential Gear Set x2
AX31131 T-Case Gear Set x1
AX30385 Diff Gasket 16x25x0.5mm x2
AX31058 Yeti™ Rear Sway Bar x1
AX31083 Radio Box Seals x1
AX31060 Spring 13x9.25mm x1
AX30249 12mm Aluminum Hub x4
AX31131 T-Case Gear Set x1
AX30392 Bevel Gear Set x2
AX30500 Heavy Duty Locker x1
AX30392 Bevel Gear Set x2
AX30842 Pinion Gear 32P 16T (5mm shaft) x1
AX30413 Slipper Spring 8.5x12 x1
AX31297 Spring 14x90mm 2.25 lbs/in - Green (2pcs) (Blue Springs) x2
AX31298 Spring 14x54mm 4.33lbs/in - Yellow (2pcs) (Blue Springs) x2
AX31296 Shock Body 12x59mm x2
AX31295 Shock Body 12x41.5mm x2

AX31148	4.5x6.5mm Joint Pin	x4
AXA1184	O-Ring 7.5x1.5mm	x4
AXA1202	O-Ring 3.5x2mm	x8
AXA1162	O-Ring 5x1mm	x4
AX30113	Rubber Bump Stop 3.6x7x4	x6
AX30112	Shock Diaphragm 13x4.5mm	x4
AXA1069	Washer 2.7x6.7x0.5 mm	x8
AXA1071	Washer 4x8x0.5mm	x2
AX30163	Pin 2x10mm	x5
AX31028	Pin 2x11mm	x9
AX30170	M3x22mm	x1
AXA1059	6mm Body Clip	x6
AXA1393	E2.5 e-clip	x4
AXA1391	E4 e-clip	x2
AXA1221	Bearing 5x11x4mm	x18
AXA1230	Bearing 10x15x4mm	x6
AXA1041	M2.5 Nylon Locking Hex Nut	x4
AXA1052	M3 Thin Nylon Locking Hex Nut	x16
AXA1053	M3 Nylon Locking Hex Nut	x7
AXA1045	M4 Nylon Lock Nut	x1
AXA1046	M4 Serrated Nylon Lock Nut	x4
AXA180	M3x3mm Set Screw (Black)	x3
AXA0181	M3x4mm Set Screw	x8
AXA291	M4x4mm Set Screw (Black)	x1
AXA0113	M3x6mm	x5
AXA114	M3x8mm	x4
AXA115	M3x10mm	x4
AXA116	M3x12mm	x8
AXA117	M3x15mm	x11
AXA118	M3x18mm	x33
AXA119	M3x20mm	x4
AXA121	M3x30mm	x2
AX31119	M3x35mm	x3
AXA0125	M3x35mm Hex Socket Button Head Screw Shaft	x2
AXA0128	M3x61mm Hex Socket Button Head Screw Shaft	x2
AXA144	M3x8mm	x4
AXA146	M3x12mm	x39
AXA0147	M3x16mm	x9
AXA148	M3x18mm	x13
AXA150	M3x25mm	x2
AXA015	M2x10mm	x10
AXA0023	M2.6x8mm	x24
AXA087	M3x16mm	x6
AXA091	M3x30mm	x1
AX31121	M4x12mm	x6
AXA0412	M2.6x6mm	x3
AXA0109	M3x10mm Oversized Flat Hex Socket	x4
AXA0413	M2.6x8mm	x3
AXA464	M3x8mm	x4
AX31061	M2.6x18mm	x2
AXA0422	M2.6x6mm	x14
AXA435	M3x10mm	x26
AXA436	M3x12mm	x7
AXA0437	M3x15mm	x12
AXA0286	M4x12mm	x6

AXA1059
AXA1059
AX31307
AX80033
AXA118
AX80033
AX80018
AXA0286
AX31111
AXA0286
AX31111
AX31148
AX31139
AXA118
AXA0147
AXA0147
AXA118
AXA0147
AXA0147
AX31112
AX31148
AX31114
AX30163
AXA0286
AXA0181
AX80033
AXA118
AX80033
AXA1221
AXA1221
AX80091
AX30408
AX30392
AX30390
AX30163
AXA1162
AXA1393
AX30385
AX30170
AXA1393
AX30390
AX30390
AXA1162
AX30392
AXA1053
AXA1162
AXA1230
AX31076
AX30381
AX30176
AX30113
AXA015
AX80018
AXA118
AX80119
AX80018
AX30418
AX1053
AX80111
AXA118
AXA117
AX80106
AX1053
AX30382
AXA118
AX80018
AX30366
AXA0181
AXA1230
AX31110
AXA1221
AXA0181
AX30382
AX30113
AX30176
AX30381
AXA1230
AX31076
AXA1162
AX80002
AXA1162
AX30390
AXA1393
AX80018
AX80119
AXA118
AX80018
AX1053
AXA1053
AX80091
AXA146
AXA146
AX31112
AXA0128
AXA0128
AXA119
AXA118
AXA116
AXA1053
AX31308
AX31308
AXA1053
AXA121
AXA121
AXA118
AXA116
AXA0181
AXA1221
AX30382
AX80018
AXA118
AX30382
AXA0181
AXA1221
AX30366
AX1053
AX80106
AXA117
AX31110
AXA1230
AX31110
AXA0181
AXA1221
AX30382
AXA0181

AXA015
AXA015
AX80070
AXA115
AXA115
AX80070
AX80070
AX30385
AX30500
AX80002
AXA1230
AXA1230
AXA1393
AX30392
AX30392
AXA087
AX30163
AXA1221
AX30408
AXA015
AXA087
AXA146
AXA119
AXA1053
AX80072
AXA144
AXA091
AX31113
AXA116
AX31113
AX31113
AX80018
AX31113
AX31113
AX31113
AXA116
AX31113
AX80018
AX31058
AX30776
AXA1221
AXA0113
AXA0113
AX80071
AXA116
AXA116
AX31125
AX31125
AX80018
AXA117
AX80018
AXA1059
AX31102
AXA118
AXA118
AXA0286
AX31102-1
AX31102
AX31102-2
AXA118
AXA118
AXA118
AXA118
AXA118
AXA180
AX31307
AX80018
AXA1052
AX80018
AXA1052
AXA144
AX31114
AX31148
AX31028
AX31148
AX31114
AXA0286
AX31148
AX31114
AXA180
AX80069
AXA1221
AXA1052
AX80070
AX1052
AXA180
AXA118
AXA1052
AX80070
AXA118
AXA144
AX31114
AXA1059
AX31307
AX31102
AXA180
AXA118
AXA118
AXA118
AXA118
AXA118

AXA148
AXA148
AXA146
AXA146
AXA146
AXA148
AXA146
AXA148
AXA146
AXA146
AXA146

AXA414
AXA414
AXA434
AXA433
AXA433
AX31049
AX31049
AX31116
AXA435
AX31116
AXA435
AXA422
AXA467
AXA436
AXA467
AXA437
AXA467
AXA467
AXA436
AXA422
AX31304
AXA422
AXA436
AXA467
AXA436
AXA467
AXA437
AXA467
AX31304
AXA422
AXA436
AXA436
AX31305
AXA436
AX31305
AX31305
AXA437
AXA439
AXA437
AX31305
AX31304
AXA436
AXA436
AXA437
AX31304
AXA422
AXA436
AXA467
AXA467
AXA437
AXA467
AXA422
AX31304
AXA422
AXA436
AXA467
AXA437
AXA467
AXA436

AX31300
AX30113
AX31298
AX31301
AXA1184
AXA1202
AX31301
AX31295
AX30147
AX80033
AXA1069
AXA1041
AX30112
AX31301
AX31300
AX30113
AX31297
AX31301
AXA1184
AXA1202
AX31301
AX31296
AX31054
AX80033
AXA1069
AXA1041
AX30112
AX31301

AX31028
AX30249
AXA180
AX31266
AX31309
AX31294
AX31294
AXA0023
AX31250
AX31028
AX30249
AXA180
AX31266
AX31309
AX31294
AX31294
AXA0023
AX31250

Parts List

Part #	Description
AX24260	AE-3 Vanguard ESC
AX30112	Shock Diaphragm 13x4.5mm (6pcs)
AX30113	Rubber Bump Stop 3.6x7x4 (6pcs)
AX30147	Shock Shaft 3x53.5mm (2pcs)
AX30163	Pin 2.0x10mm (6pcs.)
AX30170	Shaft 3 x 22 (2pcs)
AX30366	Axle 5x35mm (2pcs.)
AX30381	EXO Heavy Duty Differential Output Shaft (2pcs)
AX30382	EXO Steering King Pin (TiN Coated) (2pcs)
AX30383	EXO Heavy Duty Differential Input Shaft (2pcs)
AX30385	Diff Gasket 16x25x0.5mm (2pcs)
AX30390	Differential Gear Set
AX30392	Bevel Gear Set (38/13)
AX30408	Input Shaft 5x29mm (2pcs)
AX30413	Slipper spring 8.5x12 165 lbs/in - Black (2pcs)
AX30418	Dogbone Set 7x96mm (2pcs)
AX30429	12mm Aluminum Hub (Black) (4pcs)
AX30500	Heavy Duty Locker (2pcs)
AX30776	AR60 OCP Rear Axle Set (2pcs)
AX30842	Pinion Gear 32P 16T (5mm shaft)
AX31028	Pin 2.0x11mm (6pcs)
AX31047	Brushless 3150KV Electric Motor
AX31049	Helmet Set (Black)
AX31054	Shock Shaft 3x71mm (2pcs)
AX31058	Yeti™ Rear Sway Bar (3pcs) (Soft, Medium, Firm)
AX31059	Slipper Plate Washer 33x1mm (2pcs)
AX31060	Servo Saver Spring 13x9.25mm 104 lbs/in (2pcs)
AX31061	M2.6x18mm Hex Socket Tapping Button Head (Black) (10pcs)
AX31065	Spur Gear 32P 64T
AX31067	Slipper Plate (2pcs)
AX31068	Slipper Pad 32.8x15.2x1mm (2pcs)
AX31083	Radio Box Seals
AX31102	Yeti™ Rear Cage Components
AX31103	Yeti™ Molded Chassis Tub
AX31104	Yeti™ Chassis Components
AX31105	Yeti™ Chassis Electronic Components
AX31106	2-Speed Hi/Lo Transmission Motor Mount
AX31107	2-Speed Hi/Lo Transmission Spur Gear Cover
AX31108	2-Speed Hi/Lo Transmission Case
AX31109	Yeti™ Rear 4 Link Set
AX31110	Yeti™ Steering Knuckle Set
AX31111	Yeti™ Shock Tower and Body Post Set
AX31113	Yeti™ Rear Sway Bar Mount Set
AX31114	WB8-HD Driveshaft
AX31119	M3x35mm Hex Socket Button Head (Black) (10pcs)
AX31122	Double Shear Steering Rack
AX31125	Yeti™ Fuel Cell
AX31127	2-Speed Hi/Lo Transmission Top Shaft (5x91mm)
AX31129	2-Speed Hi/Lo Transmission Bottom Shaft (5x75mm)
AX31130	High Speed Transmission Gear Set (48P 26T, 48P 28T)
AX31131	T-Case Gear Set (32P 15T, 32P 15T, 32P 27T)
AX31134	2-Speed Hi/Lo Transmission Output Shaft (5x35mm)
AX31139	Center Driveline Universal Shaft (103mm)
AX31148	WB8-HD Driveshaft Coupler Set
AX31250	M4 Serrated Nylon Lock Nut (Black) (10pcs)
AX31266	IFD™ Hex Hub Adapter (2pcs Narrow, 2pcs Wide)
AX31294	2.2 3.0 BFGoodrich Baja T/A KR2 Tires 42mm - R35 Compound (2pcs)
AX31295	Aluminum Shock Body 12x41.5mm (Clear Anodized) (2pcs)
AX31296	Aluminum Shock Body 12x59mm (Clear Anodized) (2pcs)
AX31297	Spring 14x90mm 2.25 lbs/in - Green (2pcs) (Blue Springs)
AX31298	Spring 14x54mm 4.33lbs/in - Yellow (2pcs) (Blue Springs)
AX31300	10mm Shock Parts Tree 2 (Blue)
AX31301	10mm Shock Caps Parts Tree (Blue)
AX31302	TT-380 SCORE® Trophy Truck® Body - .040" (Clear)
AX31303	TT-380 Interior Set - .040" (Clear)
AX31304	TT-380 Rear Cage Sides and Rear Upper Cage
AX31305	TT-380 Rear Lower Cage and Tire Retainer
AX31306	TT-380 SCORE® Trophy Truck® Grille and Cage Components
AX31307	TT-380 Body Post Set
AX31308	TT-380 Front Bumper and Toe Block
AX31309	2.2 3.0 Method 105 Wheels – 41mm (Black) (2pcs)

Part #	Description
AX80002	Diff Case -Small
AX80006	Servo Set
AX80018	Hardware Parts Tree
AX80033	10mm Shock Parts Tree 1
AX80069	AR60 OCP Axle Housing
AX80070	AR60 OCP Differential Cover
AX80071	AR60 OCP Straight Axle Adapter
AX80072	AR60 OCP 4-Link Mount
AX80091	EXO Bulkhead
AX80106	EXO Steering Knuckle Carrier Set
AX80111	EXO Lower Front Control Arms Set
AX80119	EXO RTR Links Parts Tree
AXA0109	M3x10mm Oversized Flat Hex Socket (Black) (10pcs)
AXA0113	M3x6mm Hex Socket Button Head (Black) (10pcs)
AXA0125	M3x35mm Hex Socket Button Head Screw Shaft (Black) (6pcs)
AXA0128	M3x61mm Hex Socket Button Head Screw Shaft (Black) (6pcs)
AXA0147	M3x16mm Hex Socket Flat Head (Black) (10pcs)
AXA015	M2x10mm Cap Head (Black) (10pcs)
AXA0181	M3x4mm Set Screw (Black) (10pcs)
AXA0286	Screw Shaft M4x2.5x12mm (6pcs)
AXA0413	M2.6x8mm Hex Socket Tapping Flat Head (Black) (10pcs)
AXA0414	M2.6x10mm Hex Socket Tapping Flat Head (Black) (10pcs)
AXA0422	M2.6x6mm Hex Socket Tapping Button Head (Black) (10pcs)
AXA0423	M2.6x8mm Hex Socket Tapping Button Head (Black) (10pcs)
AXA0437	M3x15mm Hex Socket Tapping Button Head (Black) (10pcs)
AXA0439	M3x20mm Hex Socket Tapping Button Head (Black) (10pcs)
AXA0467	M3x16mm Hex Socket Tapping Flat Head (Black) (10pcs)
AXA086	M3x12mm Cap Head (Black) (10 pcs)
AXA087	M3x16mm Cap Head (Black) (10pcs)
AXA091	M3x30mm Cap Head - Black (10pcs)
AXA1041	M2.5 Nylon Locking Hex Nut - Silver (10pcs)
AXA1045	M4 Nylon Lock Nut (Black) (10pcs)
AXA1052	M3 Thin Nylon Locking Hex Nut (Black)
AXA1053	M3 Nylon Locking Hex Nut (Black) (10pcs)
AXA1059	6mm Body clip (Black) (10pcs)
AXA1069	Washer 2.7x6.7x0.5 (10pcs)
AXA1071	Washer 4x8x0.5mm (10pcs)
AXA114	M3x8mm Hex Socket Button Head (Black) (10pcs)
AXA115	M3x10mm Hex Socket Button Head (Black) (10pcs)
AXA116	M3x12mm Hex Socket Button Head - Black (10pcs)
AXA1162	O-Ring 5x1mm (10pcs)
AXA117	M3x15mm Hex Socket Button Head (Black) (10pcs)
AXA118	M3x18mm Hex Socket Button Head - Black (10pcs)
AXA1184	O-Ring 7.5x1.5mm (S8) - (10pcs)
AXA119	M3x20mm Hex Socket Button Head (Black) (10pcs)
AXA1202	O-Ring 3.5x2mm (10pcs)
AXA121	M3x30mm Hex Socket Button Head (Black) (10pcs)
AXA1221	Bearing 5x11x4mm (2pcs)
AXA1230	Bearing 10x15x4mm
AXA1391	E4 e-clip (10pcs)
AXA1393	E2.5 e-clip (10pcs)
AXA144	M3x8mm Hex Socket Flat Head (Black) (10pcs)
AXA146	M3x12mm Hex Socket Flat Head - Black (10pcs)
AXA148	M3x18mm Hex Socket Flat Head (Black) (10pcs)
AXA150	M3x25mm Hex Socket Flat Head (Black) (10pcs)
AXA1635	M3x35mm Turnbuckle (2pcs)
AXA180	M3x3mm Set Screw (Black) (10pcs)
AXA291	M4x4mm Set Screw (Black) (6pcs.)
AXA433	M3x6mm Hex Socket Tapping Button Head - Black (10pcs)
AXA434	M3x8mm Hex Socket Tapping Button Head (Black) (10pcs)
AXA435	M3x10mm Hex Socket Tapping Button Head (Black) (10pcs)
AXA436	M3x12mm Hex Socket Tapping Button Head (Black) (10pcs)

Option Parts

Part #	Description
AX08101	2.2 3.0 Raceline Renegade Wheels - 41mm (Black) (2pcs)
AX08103	2.2 3.0 Raceline Renegade Wheels - 41mm (Chrome/Black) (2pcs)
AX08104	2.2 3.0 Raceline Renegade Wheels - 34mm (Black) (2pcs)
AX08106	2.2 3.0 Raceline Renegade Wheels - 34mm (Chrome/Black) (2pcs)
AX12017	2.2 3.0 Hankook Dynapro Mud Terrain Tires 34mm - R35 Compound (2pcs)
AX12018	2.2 3.0 Hankook Dynapro Mud Terrain Tires 41mm - R35 Compound (2pcs)
AX24010	Brushless 2900KV Electric Motor
AX24251	Axial NVS - Night Visions System
AX24252	Axial Double LED Light String (White LED)
AX24253	Axial Double LED Light String (Red LED)
AX24254	Axial Double LED Light String (Orange LED)
AX24255	Axial Single LED Light String (White LED)
AX24256	Axial 5 LED Light String (White LED)
AX24257	Simple LED Controller w/LED lights (4 white and 2 Red)
AX24258	4 LED Light String (White LED)
AX30091	67-90mm Shock Set - 10mm Piston (2pcs)
AX30092	Axial 72-103mm Shock Set - 10mm Piston (2pcs)
AX30110	Axial Aluminum 13mm Aluminum Preload Collar (2pcs)
AX30111	Axial Aluminum Shock Cap (2pcs)
AX30120	Axial Aluminum Shock Body 12x47.5mm (2pcs)
AX30155	Shock Shaft 3x59.5 (2pcs)
AX30213	Spring 14x90mm 1.32 lbs/in - (Red)
AX30214	Spring 14x90mm 1.71 lbs/in - (White)
AX30215	Spring 14x90mm 2.25 lbs/in - Medium (Green)
AX30216	Spring 14x90mm 2.78 lbs/in - Firm (Yellow)
AX30217	Spring 14x90mm 3.01 lbs/in - Super Firm (Blue)
AX30226	Spring 14x54mm 2.64 lbs/in - Super Soft (Red) - (2pcs)
AX30227	Spring 14x54mm 3.4 lbs/in - Soft (White) - (2pcs)
AX30228	Spring 14x54mm 3.85 lbs/in - Medium (Green) - (2pcs)
AX30230	Spring 14x54mm 4.95 lbs/in - Super Firm (Blue) - (2pcs)
AX30401	Heavy Duty Bevel Gear Set - 36T/14T
AX30402	Heavy Duty Bevel Gear Set - 43T/13T
AX30709	Universal 5 Bucket Light Bar Set
AX30741	Spur Gear 32P 48T
AX30742	Spur Gear 32P 50T
AX30743	Spur Gear 32P 52T
AX30744	Spur Gear 32P 54T
AX30789	AR60 OCP Aluminum Straight Axle Hub Carrier (2pcs)
AX30811	EXO™ Machined Aluminum Front Toe Block F1 (Hard Anodized)
AX30829	AR60 OCP Machined Low-Profile Differential Cover
AX30830	Axial AR60 OCP Machined Link Mounts
AX30831	AR60 OCP™ Front Axle Set (Complete)
AX30834	Aluminum Servo Horn 23T
AX30835	Aluminum Servo Horn 24T
AX30836	Aluminum Servo Horn 25T
AX30837	Pinion Gear 32P 11T (5mm shaft)
AX30838	Pinion Gear 32P 12T (5mm shaft)
AX30839	Pinion Gear 32P 13T (5mm shaft)
AX30840	Pinion Gear 32P 14T (5mm shaft)
AX30841	Pinion Gear 32P 15T (5mm shaft)
AX30843	Pinion Gear 32P 17T (5mm shaft)
AX31074	IFD™ Hex Hub Conversion Set (12mm) (4pcs)
AX31097	3 Port High Output LED Controller
AX31098	8 LED Light String (White LED)
AX31136	Icon 87-125mm Aluminum Shock Set - 10mm Piston (2pcs)
AX31152	Universal Rigid Light Bar Set
AX31153	Spring 14x90mm 0.90 lbs/in - Black (2pcs)
AX31154	Spring 14x90mm 1.01 lbs/in - Purple (2pcs)
AX31156	Machined Adjustable Motor Mount (Hard Anodized)
AX31160	Steel Spur Gear 32P 68T
AX31161	Steel Spur Gear 32P 64T
AX31162	Steel Spur Gear 32P 60T
AX31163	Steel Spur Gear 32P 56T
AX31164	Machined Slipper Plate (Hard Anodized) (2pcs)
AX31165	Machined 4 Link Mounts (Hard Anodized) (2pcs)
AX31166	Machined Shock Mount Plates (Hard Anodized) (2pcs)
AX31167	Machined Sway Bar Clamp (Hard Anodized) (2pcs)
AX31169	Machined Body Post Mount (Hard Anodized)
AX31170	Machined Front Shock Tower (Hard Anodized)
AX31171	Icon 72-103mm Aluminum Shock Set - 10mm Piston (2pcs)
AX31172	Icon 67-90mm Aluminum Shock Set - 10mm Piston (2pcs)

Part #	Description
AX31173	Icon 93-137mm Aluminum Shock Damper Set - 10mm Piston (2pcs)
AX31174	Y-380 1/10th Scale Body - .040" (Pre-Painted) (White, Blue, Pink)
AX31182	Front Differential Locker
AX31188	Icon Aluminum Shock Body 12x47.5mm (2pcs)
AX31190	Icon Aluminum Shock Body 12x65mm (2pcs)
AX31193	Shock Shaft 3x77mm (2pcs)
AX31244	Upper Link Plate Set (Aluminum) (4pcs)
AX31266	IFD™ Hex Hub Adapter (2pcs Narrow, 2pcs Wide)
AX31249	Yeti™ Turnbuckle Set (Aluminum) (4pcs)
AX31272	M4x55mm Turnbuckle (Steel) (2pcs)
AX31273	M4x60mm steel turnbuckle
AX31310	TT-380 SCORE® Retro Trophy Truck® Body - .040" (Clear)
AX31311	TT-380 SCORE® Retro Trophy Truck® Grille and Cage Components
AX31325	2.2 BFGoodrich Baja T/A KR2 Tires - R35 Compound (2pcs)
AX31326	2.2 Walker Evans Wheels - Black (2pcs)
AX80085	Universal Mount 5 Bucket Light Bar (Black)
AX80086	Light Bar Lenses (Clear) (5pcs)
AX80131	Helmet Set
AXA1076	Cap Head Washer M3x10mm (4pcs)
AXA1101	Cone Washer 3x6.9x2mm (6pcs)
AXA1104	Cone Washer 3x6.9x2mm - Orange (6pcs)
AXA1105	Cone Washer 3x6.9x2mm - Grey (6pcs)
AXA1331	Flanged Ball 3x5.8x7mm (6pcs)
AXA1412	0.5x6mm Spacer - Grey (6pcs)
AXA1413	1x6mm Spacer - Grey (6pcs)
AXA1414	2x6mm Spacer - Grey (6pcs)
AXA1415	3x6mm Spacer - Grey (6pcs)
AXA1416	4x6mm Spacer - Grey (6pcs)
AXA1417	5x6mm Spacer - Grey (6pcs)
AXA1418	6x6mm Spacer - Grey (6pcs)
AXA1419	7x10mm Post - Grey (2pcs)
AXA1420	7x15mm Post - Grey (2pcs)
AXA1421	7x20mm Post - Grey (2pcs)
AXA1422	7x25mm Post - Grey (2pcs)
AXA1423	7x30mm Post - Grey (2pcs)
AXA1424	7x35mm Post - Grey (2pcs)
AXA1425	7x40mm Post - Grey (2pcs)
AXA1426	7x45mm Post - Grey (2pcs)
AXA1427	7x50mm Post - Grey (2pcs)
AXA1428	7x55mm Post - Grey (2pcs)
AXA1429	7x60mm Post - Grey (2pcs)
AXA1430	7x65mm Post - Grey (2pcs)
AXA1431	7x70mm Post - Grey (2pcs)

DON'T SETTLE FOR
NORMAL BEHAVIOR

©2013 Axial R/C, Inc. A subsidiary of Hobbico, Inc. All Rights Reserved.

READY TO RUN

AX10™ DEADBOLT™ 1/10th SCALE ELECTRIC 4WD #AX90033

OFFICIALLY LICENSED TECHNICAL PARTNERS:

MAXXIS Raceline wheels ICON VEHICLE DYNAMICS DANA 60

axial®

www.axialracing.com

SCX10

THE OFFICIAL TRUCK OF THE R.E.C.O.N. G6 CHALLENGE

DO WORK DRIVER™

AWCC 2011

SCX10™ FEATURES:

- > SCALE LOOKS WITH METAL TO MATCH!!!
- > TRUE STEEL C-CHANNEL FRAME
- > SOLID AXLE DESIGN WITH HARDENED STEEL INNER AXLES FRONT AND BACK
- > TRUE RING AND PINION MECHANICAL DIFFERENTIALS
- > COIL OVER SHOCKS
- > STRONG 4X4 TRANSMISSION / TRANSFER CASE ALL-IN-ONE
- > FULL METAL BEARINGS IN AXLES AND TRANSMISSION - RUBBER SEALED FOR MAXIMUM PROTECTION

If you are looking for adventure, the RECON G6 Challenge™ is where it's at. RECON G6 Challenge™ events deliver excitement and push boundaries; always bringing the elements of what a real adventure should deliver - the unknown!

The coolest thing about participating in the G6 Challenge™ is that it is not about the podium, it's all about the finish. It's about the massive amount of drive time and perservering to survive the unknown-unscathed; and then sharing stories at the end of the day - "How in the heck did you clear TM-24 on the 100-course?" "Did you see that Bender-6X walk-it?!" "Did you get passed by the Swanson Swagger!?"

For adventure G6'ers, the rougher and less traveled, the better! It is the adventure of a lifetime for man and scale machine against the elements. The G6 is about battling the course with your comrades, work as an individual or help your fellow G6'ers to overcome the obstacles; survival is the name of the game!

In an adventure, chasing the unknown requires confidence. Confidence = reliability = SCX10™. The Axial SCX10™ - the official truck of the RECON G6 Challenge™!

Visit our blog and start the adventure!

SCX10

THE SCX10™ MODEL RANGE:

AX90021
DINGO™
KIT (UNASSEMBLED)

AX90022
TRAIL HONCHO™
RTR (READY-TO-RUN)

AX90027
JEEP® WRANGLER UNLIMITED RUBICON
KIT (UNASSEMBLED)

AX90028
JEEP® WRANGLER UNLIMITED RUBICON
RTR (READY-TO-RUN)

© 2013 Axial R/C Inc. A subsidiary of Hobbico, Inc.
Jeep and the Jeep grille are registered trademarks of Chrysler Group LLC and are used under license. ©2013 Chrysler Group LLC.

axial®

www.axialracing.com

OFFICIALLY LICENSED TECHNICAL PARTNERS:

EXPLORE

facebook.com/axialinc | twitter.com/axialrc | youtube.com/axialvideos | flickr.com/axialrc

axial®

www.axialracing.com

BFGoodrich® Tires and Baja T/A® KR2 Trademarks are used under License from Michelin

Trophy Truck and SCORE are registered trademarks of SCORE International and used under license.

AX90050-1001